



MicroVault[®]

MV500 | MV1000 | MVB500 | MVB1000

FASTER. SAFE. TOUGH.





The Leader in Responsible Firearm Storage

Since 1990, **GunVault** has been an industry leader and innovator of quick access personal safes. We pride ourselves on our commitment to manufacture firearm storage solutions that provide the highest level of quality and security that you need. At **GunVault**, we understand that in a time of crisis you rely on quick access and unbeatable security.

We are honored that you have selected our products and welcome to the **GunVault** family.

Index

»» Quick Start Guide	4
Battery Installation	
Programming	
Digital Unit	
Resetting the Passcode	
Biometric Unit	
Additional Users	5
Opening Safe with Biometric Scanner	
Resetting the Unit	
»» Product Features	6
Digital	
Biometric	
»» Safety Features Section	7
Tamper Detection	
Audio Control	
Security Sleep Mode	
Low Battery Warning Indicator	
Security Cable	
Installing the Elastic Strap	
»» Warnings	9
»» GunVault Exclusive 5 Year Warranty	10
»» Warranty Registration	11

Quick Start Guide

»» Battery Installation

The lock manufacturer highly recommends using either a Duracell or Energizer 9V alkaline battery with an expiration date of 5 years into the future.

Step 1: Use the backup keys to unlock the unit.

Step 2: Locate the battery compartment on the front interior panel; open and insert the recommended 9V alkaline battery.

Step 3: When the battery is connected, you will hear a single beep signaling that the unit is powered.

Programming

»» Digital Unit

Step 1: Open the unit with the backup key provided or by using the factory default code. The default code is a single sequential press of each button from left to right.

Step 2: Press and hold the Learn button located on the front interior panel. A beep will sound, and the light will turn green and remain illuminated. This light indicates the lock is ready to be programmed.

Step 3: The indicator light will remain activated as you enter the new access code. The code can be a minimum of three entries or maximum of six entries.

Step 4: Press and hold the Learn button a second time until the safe beeps, and the indicator light turns red and remains illuminated. Re-enter the new access code.

Step 5: Press and hold the Learn button one last time until the indicator light flashes green and beeps five times. If the indicator light flashes red and beeps five times, an error has occurred and you will need to repeat steps 2-5.

Step 6: Test your new code and repeat steps 2-5 if necessary.

Step 7: Your unit is programmed and ready to use.

»» Resetting the Passcode

Step 1: Open the unit using either your backup key or current access code. Locate the Learn button which can be found on the front interior panel of the unit.

Step 2: Use steps 2-5 in the Programming Digital Keypad section to change your current combination.

Step 3: Now you have successfully reprogrammed your safe.

»» Biometric Unit

New units are set in DEMO mode, meaning the unit can be opened without a fingerprint.

Step 1: Open the unit by pressing the START button, which is located above the biometric scanner.

Step 2: Press and release the LEARN/MUTE button located on the interior panel until the indicator light flashes green/red and beeps once. If the indicator light stops flashing at any point, the unit has timed out and you will need to press the button again.

Step 3: While the indicator light is flashing, place the tip of your finger over the biometric scanner and make a 1-2 second downward swiping motion. The indicator light will flash green and you will hear a beep. If the light flashes red, the swipe was unsuccessful, and you will need to repeat step three.

Step 4: Keep swiping your finger until you hear a double beep. A double beep indicates the enrollment of your fingerprint was successful.

Step 5: Test the unit to ensure that your fingerprint was successfully programmed.

Step 6: Repeat all steps to add up to 20 fingerprints.

»» Programming Additional Users

Leave the unit door open while you program your safe. After enrolling the first two administrator fingerprints, you will be able to program additional users.

Step 1: Open the unit using the biometric scanner function.

Step 2: Press the LEARN button in the interior panel twice. The unit will beep once, and the indicator light will flash.

Step 3: While the indicator light is flashing, swipe the administrator fingerprint over the biometric scanner until you hear two beeps. You can now program additional fingerprints. If at any point the indicator light stops flashing, you will need to start from the beginning.

Step 4: Place the tip of the new fingerprint at the top of the biometric scanner and make a slow, downward swiping motion. It may take 2-3 swipes to program.

Step 5: The unit will beep twice and the indicator light will flash green. The fingerprint was successfully enrolled. Test your unit using the new fingerprint.

Step 6: To enroll additional fingerprints/users, repeat steps 2-5. You can enroll up to 20 unique fingerprints.

»» Opening the Safe Using the Biometric Scanner

Step 1: Press the START button.

Step 2: Using a previously enrolled fingerprint, place your finger on top of the scanner.

Step 3: The indicator light will flash green and beep twice when the fingerprint is accepted. The safe will then open.

Note: If the light flashes green and then red, your fingerprint was not accepted, and you will need to try again.

»» Resetting the Unit

Individual users cannot be deleted from the unit. All users must be deleted in order to remove any one fingerprint or the unit must be reset.

Step 1: Open the unit using a fingerprint or the keys that were provided. Locate the DELETE/MUTE button in the interior front panel of the unit.

Step 2: Press and hold the DELETE/MUTE button.

Step 3: While pressing the DELETE button, press the START button to activate the unit.

Step 4: Continue to hold the DELETE button until the indicator light stops flashing. Once the light has stopped, you can release the DELETE button.

Step 5: All fingerprints have been deleted. Follow the steps under Programming to reprogram your unit.

Product Features

(Digital MicroVault | Digital MicroVault XL)

1. Indicator Light
2. Digital Keypad
3. Battery Holder
4. Learn Button
5. Mute Button
6. Elastic Strap
(MV1000 | MVB1000 units only)
7. Backup Keys
8. Keypoint
9. High-Strength Steel
Security Cable



Product Features

(Biometric MicroVault | Biometric MicroVault XL)

1. Indicator Light
2. Start Button
3. Biometric Scanner
4. Battery Holder
5. Learn Button
6. Delete Button
7. Keypoint
8. Elastic Strap
(MV1000 | MVB1000 units only)
9. Backup Keys
10. High-Strength Steel
Security Cable



Safety Feature Section

»» Tamper Detection

Entering an invalid access code triggers the Tamper Detection feature.

Step 1: Press and hold buttons 2 and 3 for five seconds to initiate the Tamper Detection indicator.

Step 2: If tampering has been detected, the indicator light will illuminate red until buttons 2 and 3 are released.

Step 3: If tampering is not detected, the light will remain green until buttons 2 and 3 are released.

»» Audio Control

This feature turns unit's audio on and off.

Step 1: Open the unit and locate the Mute button on the front interior panel of the unit.

Step 2: Press and hold the Mute button for three (3) seconds. The indicator light will remain red and produce one audible beep while the Mute button is compressed. When the indicator light flashes green three times, with no beep, you have successfully activated the mute audio control feature. When the same steps are followed and the indicator light flashes green and beeps three times, you have successfully deactivated the mute audio control feature.

»» Security Sleep Mode

After six incorrect entries, the Security Sleep Mode feature will activate and will lockout any new keypad entries for two minutes. When Security Sleep Mode is active, and a button is pressed, the indicator will flash red and beep three times.

To verify that the Security Sleep Mode is deactivated, wait two minutes and then test your unit by slowly typing in your combination. If the indicator flashes green, your combination is accepted, and the unit will open. If the indicator flashes red, your combination is incorrect; you will need to try again. If you have forgotten or lost your combination, please follow the instructions under Programming Digital Keypad. Your backup key will be required if reprogramming is needed.

»» Low Battery Warning Indicator

Step 1: When you enter the correct combination and the battery is low, the indicator light will flash red and beep seven times.

Step 2: Replace battery using steps in section labeled Battery Installation.

***The low battery indicator only goes off when you are in the process of opening your unit.**

»» Security Cable

The unit includes a 4-foot long, high strength, steel security cable. This cable is intended to securely tether the safe to a sturdy surface.

Step 1: Loop the cable around a sturdy, immovable object.

Step 2: Find the end of the cable with the metal tip and run it through the eye of the cable. Pull it taut so it wraps tightly around the sturdy surface.

Step 3: Place the metal end of the security cable through the fitted slot on the top left side of the unit. Close the lid to secure the cable.

»» Installing the Elastic Strap

(MicroVault XL Units Only)

Step 1: Open the unit by using your keys or code.

Step 2: Locate the metal slot on both sides of the unit's interior roof.

Step 3: Take the metal portion of the elastic strap and insert into the metal slots on either side.

Step 4: Repeat previous step on opposite side.

Step 5: Your elastic strap is ready for use.

Safes, Accesories and More!

Loving your new GunVault safe and want to purchase more?

Check out our website www.GunVault.com for special promotions, product information and more.

»» SAFE CATEGORIES »» ACCESSORIES »» VITAL INFORMATION

- Digital Safes
- Biometric Safes
- AR Safes
- Security cable
- MagVault
- Downloadable manuals
- How-to video tutorials
- Warranty registration
- Frequently Asked Questions
- and MORE

VISIT OUR WEBSITE FOR FAQ'S, VIDEO TUTORIALS AND MORE.

Safety Warnings

- Always keep your safe closed and locked when not in use.
- Children should not play with, around or in any safe at any time.
- Keep backup keys and access code combinations in a secure place away from children.
- Keep the included high-strength steel security cable in a secure place away from children.
- This safe or any other firearm storage device cannot take the place of other safety procedures, including advising children of the dangers of firearms.
- Keep a record of your key number and serial number in a secure place separate from your safe.
- To enjoy the maximum-security benefits of this safe, it must be mounted in place. Use of this product as a storage receptacle without mounting may compromise security of the safe.
- Do not mount any GunVault product with the door facing down. The contents may fall out when the door is opened.

⚠ WARNING: This product can expose you to chemicals including Di(2-ethylhexyl)phthalate (DEHP) which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to P65Warnings.ca.gov

Important Notices

- The backup key is for emergency use only in the event of fingerprint failure or forgotten passcode. For replacement keys, visit GunVault.com/owner-center/key-replacement-form/ to complete the online key replacement form. To receive a replacement key, you will need to know the key number associated with your unit. You can find this information on the unit engraved on the key port.
- The manufacturer recommends that you lightly coat the door hinge spring and door latch-loop with quality oil at least once a year. Never spray anything into the latch mechanism as it can damage the safe.
- Do not try to remove the key while in the turned position. This may damage the unit or key.

Firearm Safety

The manufacturer of this product does not recommend, suggest, advise, promote, or otherwise condone the ownership or use of firearms. We at GunVault believe the decision to own or use a firearm is a serious decision that should only be made by an adult who has carefully considered the risks and benefits of such a decision. GunVault recommends that you obtain as much information as possible on firearm safety. Always handle firearms as if they are loaded and ready to fire. Never drink alcohol or use drugs while operating this safe or any firearm. Never grab your firearm by the trigger when removing or placing in to safe. Always keep your firearm safety mechanism engaged while stored inside the safe. Always follow the firearm safety rules set out by the firearm's manufacturer.

GunVault Exclusive 5 Year Warranty

1. GunVault (the "Company") warrants to the original consumer (the "Purchaser") of any GunVault safe (the "GunVault safe") purchased after January 1, 2014 against any damage caused by fire, burglary or attempted burglary for a period of five (5) years from the date of purchase.
2. The Company warrants to the purchaser that the GunVault safe will be free from defects in workmanship and materials for a period of one (1) year from the date of purchase.
3. These warranties are not assignable or transferable to any other person.
4. Any damage to the GunVault safe as a result of misuse, tampering, abuse, neglect, accident, improper installation, modification, unauthorized service, destruction, or the alteration of the serial number, or use in violation of the instructions furnished by the Company will void this warranty.
5. The sole responsibility of the Company shall be limited to the repair or replacement (in its sole discretion) of any component of the GunVault safe which fails to conform to this warranty at no cost to the purchaser for the period of the warranty.
6. Contact the Company directly to obtain service under this warranty. If it becomes applicable to send a defective product to the Company, a Return Authorization Number must first be obtained from the company. In order to obtain service under this warranty, purchaser must provide the Company with the following items (a) proof of purchase, (b) police or fire department report, (c) photographs of damaged safe, and (d) written testimonial.
7. Products shipped without prior Return Authorization and Return Authorization Number may not be accepted, and the Company will not be responsible for their disposition and/or cost of return to the owner.
8. The Company will not assume any responsibility for any loss or damage incurred in shipping. All return authorized products should include a copy of the original invoice in order for this warranty to be honored.
9. This warranty is not an insurance policy. The Company is not responsible for any manner of damage to or theft of the Purchaser's GunVault safe or its contents.
10. We recommend that the warranty registration be completed online in order to validate this warranty.
11. Any implied warranties that the purchaser may have are limited to the duration of the warranties described above. There are no further warranties that extend or apply beyond the face hereof, and the company expressly disclaims and excludes any and all warranties of merchant ability or fitness for a particular purpose. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.
12. Repair or replacement shall be the sole remedy for the purchaser under this warranty. The company shall not be liable for any direct, indirect, incidental or consequential damages, losses or expense arising from the use or misuse of the GunVault safe. Some states do not allow the exclusion or limitations of incidental or consequential damages, so the limitation may not apply to you.
13. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.
14. This warranty is only valid in the United States. If outside of the U.S. we encourage you to contact your point of purchase for further warranty help.



Please visit GunVault.com for Replacement Promise details*

GUNVAULT PRODUCT REGISTRATION

To submit your warranty registration, go to www.GunVault.com/owner-center/product-registration/ or call our Customer Service Department at (847) 665-1626.

For key replacement visit the GunVault.com/owner-center/key-replacement-form/ to complete the online key replacement form. In order to receive a replacement key you will need to know the key number associated with your unit. You can find this information on the unit engraved on the keyport.

**PLEASE FILL OUT THE SECTION BELOW AND STORE
IN A SAFE LOCATION OUTSIDE OF YOUR UNIT.**

THIS IS NOT A REGISTRATION FORM

Safe Model:

Purchased from:

Date of Purchase:

Serial Number:

(This number can be found inside unit)

Key Number:

SAFE QUICK STRONG SMART®



Customer Support Hours:

Monday - Friday 6:00 am - 4:00 pm (PST)

Excluding Holidays *Hours subject to change

(847) 665-1626

© 2021 CANNON SECURITY PRODUCTS

2895 W. Capovilla Avenue Suite 140

Las Vegas, Nevada 89119

GunVault.com



GunVault®

THE ORIGINAL. SINCE 1990