



XTRM Vault™

EXV1000

FASTER. SAFE. TOUGH.



Index

»» Product Features	3
Battery Installation	
Programming	
»» Safety Features Section	4
Audio Control	
Security Sleep Mode	
»» Low Battery Warning Indicator	5
»» Warnings	6
»» GunVault Exclusive 5 Year Warranty	7
»» Warranty Registration	8

GunVault The Leaders in Responsible Firearm Storage


Since 1990, **GunVault** has been an industry leader and innovator of quick access personal safes. We pride ourselves on our commitment to manufacture a responsible firearm storage solutions with the highest in quality and patented design. At **GunVault** we understand that in a time of crisis you rely on the security and protection GunVault provides.

Thank you for your trust and welcome to the **GunVault** family.

Product Features

(XTRMVault)

1. Indicator Light
2. Digital Keypad
3. Battery Compartment
4. Learn Button
5. Mute Button
6. Keypoint
7. Backup keys



»» Battery Installation

The lock manufacturer highly recommends using either a Duracell or Energizer 9V alkaline battery with an expiration date of 5 years into the future.

Step 1: Use the backup keys to unlock the unit.

Step 2: Locate the battery compartment on the front interior panel; open and insert the recommended 9V alkaline battery.

Step 3: When the battery is connected, you will hear a single beep signaling that the unit is powered.

Always hold the battery connection cap while disconnecting or attaching a new battery. Do not pull on the power cables as this could cause the power supply to become disconnected from the lock.

Never attempt to plug in a battery charger of any kind. Fire or explosion of batteries could result.

The AC/DC power supply specified, if equipped, is NOT a battery charger. It is an external power supply to be used only when batteries are installed.

Never attempt to operate the safe with external power alone (if equipped). Batteries MUST be installed before and during operation with the external power supply in order to avoid interruption of power and loss of access codes.

Never use rechargeable batteries of any kind in a GunVault safe. Their power characteristics are not compatible with the safe.

Do not store backup keys inside the safe.

»» Programming

Step 1: Open the unit with the backup key provided or by using the factory default code. The default code is a single sequential press of each button from left to right.

Step 2: Press and hold the Learn button located on the front interior panel. A beep will sound, and the light will turn green and remain illuminated. This light indicates the lock is ready to be programmed.

Step 3: The indicator light will remain activated as you enter the new access code. The code can be a minimum of three entries or maximum of six entries on the keypad.

Step 4: Press and hold the Learn button a second time until the safe beeps, and the indicator light turns red and remains illuminated. Re-enter the new access code.

Step 5: Press and hold the Learn button one last time until the indicator light flashes green and beeps five times. If the indicator light flashes red and beeps five times, an error has occurred and you will need to repeat steps 2-5.

Step 6: Test your new code and repeat steps 2-5 if necessary.

Your unit is programmed and ready to use.

»» Resetting the Passcode

Step 1: Open the unit using either your backup key or current access code. Locate the Learn button which can be found on the front interior panel of the unit.

Step 2: Use steps 2-5 in the Programming Digital Keypad section to change your current combination.

You have successfully reprogrammed your safe.

Safety Feature Section

»» Audio Control

This feature turns unit's audio on and off.

Step 1: Open the unit and locate the Mute button on the front interior panel of the unit.

Step 2: Press and hold the Mute button for three (3) seconds. The indicator light will remain red and produce one audible beep while the Mute button is compressed. When the indicator light flashes green three times, with no beep, you have successfully activated the mute audio control feature. When the same steps are followed and the indicator light flashes green and beeps three times, you have successfully deactivated the mute audio control feature.

»» Security Sleep Mode

After six incorrect entries, the Security Sleep Mode feature will activate and will lockout any new keypad entries for two minutes. When Security Sleep Mode is active, and a button is pressed, the indicator will flash red and beep three times.

To verify that the Security Sleep Mode is deactivated, wait two minutes and then test your unit by slowly typing in your combination. If the indicator flashes green, your combination is accepted, and the unit will open. If the indicator flashes red, your combination is incorrect; you will need to try again. If you have forgotten or lost your combination, please follow the instructions under Programming Digital Keypad. Your backup key will be required if reprogramming is needed.

»» Low Battery Warning Indicator

Step 1: When you enter the correct combination and the battery is low, the indicator light will flash red and beep seven times.

Step 2: Replace battery by using steps in section labeled Battery Installation.

***The low battery indicator only goes off when you are in the process of opening your unit.**

»» Battery Replacement Warning

Replace the batteries once a year regardless of whether the low battery indicator light is triggered.

Safes, Accesories and More!

Loving your new GunVault safe and want to purchase more?

Check out our website www.GunVault.com for special promotions, product information and more.

»» SAFE CATEGORIES »» ACCESSORIES »» VITAL INFORMATION

- Digital Safes
- Biometric Safes
- AR Safes
- Security cable
- MagVault
- Downloadable manuals
- How-to video tutorials
- Warranty registration
- Frequently Asked Questions
- and MORE

VISIT OUR WEBSITE FOR FAQ'S, VIDEO TUTORIALS AND MORE.

Safety Warnings

- Always keep your safe closed and locked when not in use.
- Children should not play with, around or in any safe at any time.
- Keep backup keys and access code combinations in a secure place away from children.
- Keep the included high-strength steel security cable in a secure place away from children.
- This safe or any other firearm storage device cannot take the place of other safety procedures, including advising children of the dangers of firearms.
- Keep a record of your key number and serial number in a secure place separate from your safe.
- To enjoy the maximum-security benefits of this safe, it must be mounted in place. Use of this product as a storage receptacle without mounting may compromise security of the safe.
- Do not mount any GunVault product with the door facing down. The contents may fall out when the door is opened.

⚠ WARNING: This product can expose you to chemicals including Di(2-ethylhexyl)phthalate (DEHP) which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [P65Warnings.ca.gov](https://www.P65Warnings.ca.gov)

Important Notices

- The backup key is for emergency use only in the event of fingerprint failure or forgotten passcode. For replacement keys, visit [GunVault.com/key-replacement-form/](https://www.GunVault.com/key-replacement-form/) to complete the online key replacement form. To receive a replacement key, you will need to know the key number associated with your unit. You can find this information on the unit engraved on the key port.
- The manufacturer recommends that you lightly coat the door hinge spring and door latch-loop with quality oil at least once a year. Never spray anything into the latch mechanism as it can damage the safe.
- Do not try to remove the key while in the turned position. This may damage the unit or key.

Firearm Safety

The manufacturer of this product does not recommend, suggest, advise, promote, or otherwise condone the ownership or use of firearms. We at GunVault believe the decision to own or use a firearm is a serious decision that should only be made by an adult who has carefully considered the risks and benefits of such a decision. GunVault recommends that you obtain as much information as possible on firearm safety. Always handle firearms as if they are loaded and ready to fire. Never drink alcohol or use drugs while operating this safe or any firearm. Never grab your firearm by the trigger when removing or placing in to safe. Always keep your firearm safety mechanism engaged while stored inside the safe. Always follow the firearm safety rules set out by the firearm's manufacturer.

GunVault Exclusive 5 Year Warranty

1. GunVault (the "Company") warrants to the original consumer (the "Purchaser") of any GunVault safe (the "GunVault safe") purchased after January 1, 2014 against any damage caused by fire, burglary or attempted burglary for a period of five (5) years from the date of purchase.
2. The Company warrants to the purchaser that the GunVault safe will be free from defects in workmanship and materials for a period of one (1) year from the date of purchase.
3. These warranties are not assignable or transferable to any other person.
4. Any damage to the GunVault safe as a result of misuse, tampering, abuse, neglect, accident, improper installation, modification, unauthorized service, destruction, or the alteration of the serial number, or use in violation of the instructions furnished by the Company will void this warranty.
5. The sole responsibility of the Company shall be limited to the repair or replacement (in its sole discretion) of any component of the GunVault safe which fails to conform to this warranty at no cost to the purchaser for the period of the warranty.
6. Contact the Company directly to obtain service under this warranty. If it becomes applicable to send a defective product to the Company, a Return Authorization Number must first be obtained from the company. In order to obtain service under this warranty, purchaser must provide the Company with the following items (a) proof of purchase, (b) police or fire department report, (c) photographs of damaged safe, and (d) written testimonial.
7. Products shipped without prior Return Authorization and Return Authorization Number may not be accepted, and the Company will not be responsible for their disposition and/or cost of return to the owner.
8. The Company will not assume any responsibility for any loss or damage incurred in shipping. All return authorized products should include a copy of the original invoice in order for this warranty to be honored.
9. This warranty is not an insurance policy. The Company is not responsible for any manner of damage to or theft of the Purchaser's GunVault safe or its contents.
10. We recommend that the warranty registration be completed online in order to validate this warranty.
11. Any implied warranties that the purchaser may have are limited to the duration of the warranties described above. There are no further warranties that extend or apply beyond the face hereof, and the company expressly disclaims and excludes any and all warranties of merchant ability or fitness for a particular purpose. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.
12. Repair or replacement shall be the sole remedy for the purchaser under this warranty. The company shall not be liable for any direct, indirect, incidental or consequential damages, losses or expense arising from the use or misuse of the GunVault safe. Some states do not allow the exclusion or limitations of incidental or consequential damages, so the limitation may not apply to you.
13. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.
14. This warranty is only valid in the United States. If outside of the U.S. we encourage you to contact your point of purchase for further warranty help.



Please visit GunVault.com for Replacement Promise details*

GUNVAULT PRODUCT REGISTRATION

To submit your warranty registration, go to www.GunVault.com/warranty or call our Customer Service Department at (847) 665-1626.

For key replacement visit the GunVault.com/key-replacement-form to complete the online key replacement form. In order to receive a replacement key you will need to know the key number associated with your unit. You can find this information on the unit engraved on the keyport.

**PLEASE FILL OUT THE SECTION BELOW AND STORE
IN A SAFE LOCATION OUTSIDE OF YOUR UNIT.**

THIS IS NOT A REGISTRATION FORM

Safe Model:

Purchased from:

Date of Purchase:

Serial Number:

(This number can be found inside unit)

Key Number:

SAFE QUICK STRONG SMART®



Customer Support Hours:

Monday - Friday 6:00 am - 4:00 pm (PST)

Excluding Holidays *Hours subject to change

(847) 665-1626

© 2021 CANNON SECURITY PRODUCTS

2895 W. Capovilla Avenue Suite 140

Las Vegas, Nevada 89119

GunVault.com